



INSTALLING BATTERIES

#15914 • LED TENT AND TRAIL LANTERN

- Step 1.** Turn battery base counter clock-wise to open.
- Step 2.** Install batteries per pole position as indicated within the battery chamber.
- Step 3.** Hold rotating battery cap to align arrows.
- Step 4.** Insert runners into groves, push down and rotate clockwise to lock as pictured below.

QUESTIONS:

If you should have any questions, problems or comments, please call our Customer Service Department at 1-800-231-1402 or e-mail info@texsport.com. This Department is open M-F from 8 a.m.-5 p.m. CST.

