


**Item 15993
Portable Table Lamp**

Thank you for buying a Texsport Authentic Adventure Gear Product. We hope you enjoy your new lamp and that it will serve you with many years of camping pleasure. We encourage you to read and understand each step of the set-up instructions prior to working with the lamp.


Do not apply excessive force to this product.

PARTS LIST:

- A - Light Attachment**
- B - Lamp Shade**
- C - Lamp Base**
- D - Shade Holder**



STEP 1 - Turn over the lamp base and take off the battery cover.



STEP 2 - Insert batteries as shown above. Replace the battery cover.




STEP 3 - Looking down into the lamp base, you'll notice 2 small notches. This is where the light attachment will fit.




STEP 4 - Line up the light attachment notches making sure the metal conductor faces the front.



STEP 5 - Insert and turn clockwise to lock into place.



STEP 6 - Snap the lamp shade holder into the 2 holes on the light attachment.



STEP 7 - Slide the lamp shade onto the lamp shade holder.

QUESTIONS:

If you should have any questions, problems or comments, please call our Customer Service Department at **1-800-231-1402**. This Department is open M-F from 8 a.m.-5 p.m. CST. www.texsport.com