



INSTRUCTIONS

12" Kerosene Lantern - #15998

**This lantern is designed to use kerosene lamp oil only!
All other fuels should not be used under any circumstances!**

Thank you for buying a Texsport Authentic Adventure Gear Product. We hope you enjoy your new lantern and that it will serve you with many years of camping pleasure. We encourage you to read and understand each step of the instructions prior to working with the lantern.

FILLING THE LANTERN:

- Step 1... Do not fill this product near heat, smoldering fire, or open flame!
- Step 2... Wait until product has completely cooled if refueling is necessary.
- Step 3... Over filling may cause the fuel to spill out of the burner sockets onto the inner air chamber and leak out the side tube joint. This can present a serious fire hazard!
- Step 4... If a fuel spill occurs, promptly clean the product and all surfaces that may have come in contact with the fuel with a disposable rag or cloth. Do not ignite or expose product near flame until all surfaces have been properly cleaned and dried of any fuel residue.
- Step 5... Do not transport unless fuel tank is empty.

LIGHTING THE LANTERN:

Wick should be adjusted so that it is no more than 1/16" above the flame plate. As the lantern warms to normal operating temperature, the flame will increase in size. Five minutes after lighting, the flame may be adjusted to provide maximum illumination. If the wick is set too high, smoking will occur, which means a sooted globe and possible globe breakage!

TRIMMING THE WICK:

Our lanterns are shipped from the factory with wicks properly trimmed. With steady use, the wick will need trimming occasionally. Trim off charred tip with sharp scissors so that the top of the wick is flat and square, making right angles at the corners.

HANDLING & STORAGE:

- Step 1... Keep out of reach of children
- Step 2... Do not expose to heat, sparks, or flame. Do not store where temperatures may exceed 120° F.
- Step 3... Do not use if the main house globe has been damaged or broken.
- Step 4... Always inspect this product for fuel leakage, dirt, or other debris which may alter the performance of this product.
- Step 5... Always extinguish product before going to sleep.
- Step 6... All burning appliances emit carbon monoxide. Ample ventilation must be provided to avoid endangering your life.
- Step 7... Always follow product instructions.

QUESTIONS:

If you should have any questions, problems or comments, please call our Customer Service Department at 1-800-231-1402. This Department is open M-F from 8 a.m. – 5 p.m. CST.