

LANTERN BATTERY INSTALLATION:

1. Turn lantern upside down and unscrew base as shown in Fig. 1.
2. Remove battery cartridge and insert batteries.
3. Insert battery cartridge with arrow pointing down as shown in Fig. 2.
4. Screw base back on.

**Fig. 1****TO REMOVE TORCHES:**

1. Release safety latches to remove side torches Fig. 3.

TORCH BATTERY INSTALLATIONS:

1. Remove battery cap and install batteries as shown in Fig. 4.

**Fig. 2****LANTERN OPERATIONS INSTRUCTIONS:**

1. Press top button once for one side panel lighting.
2. Press top button twice for two side panel lighting.
3. Press button on removable torches to light the third and fourth side panels.

**Fig. 3****TORCH OPERATIONS INSTRUCTIONS:**

1. Press on button once for flashlight.
2. Press on button twice for panel lighting.

QUESTIONS:

If you should have any questions, problems or comments, please call our Customer Service Department at 1-800-231-1402 or e-mail info@texsport.com. This Department is open M-F from 8 a.m.-5 p.m. CST.

**Fig. 4**