



Authentic Adventure Gear®

INSTRUCTIONS


#01084 - Privacy Shelter

Thank you for purchasing this Texsport shelter. Please read and understand each step of the set-up instructions. We encourage you to set-up this shelter at least once prior to your camping trip, ensuring that you have a satisfactory understanding of the set-up process. We hope you enjoy your new shelter and that it will give you many years of camping pleasure.

Do not apply excessive force to this product.

PARTS LIST:

- A4 Bottom leg poles**
- B4 Center leg poles**
- C4 Top leg poles**
- D4 Roof poles**
- EShelter skin**
- F4 Curved roof poles**
- GGuy ropes, clews and stakes**



NOTE:

Prepare your camp site by removing all sharp stones, twigs, etc. The site should be flat and have no depressions that could collect rain water.



STEP 1 - Spread out the shelter skin with clear roof panel facing up.



STEP 2 - Insert a curved roof pole (F) through the loop as shown above. Then insert a roof pole (D) on each side of the curved pole.




STEP 3 - Repeat step 2 for the other sides. This is how your roof frame should look.




STEP 4 - Secure shelter skin by attaching the hook 'n' loop to the frame.



STEP 5 - Adjust shelter skin so the side tabs are accessible.



STEP 6 - Assemble the leg poles as shown above.



STEP 7 - Starting at the bottom of the shelter skin, push one assembled leg pole through the web straps as shown. Insert the pin into the hole of the curved roof pole as shown in Step 11.



STEP 8 - Repeat Step 7 for the remaining three sides.



STEP 9 - Turn the shelter upright and adjust the frame so that the shelter skin is tight.




STEP 10 - Guy ropes must be used to secure your shelter especially in windy conditions. Insert the guy rope into clew as shown above.




STEP 11 - Tie the other end of the guy rope to the top of the frame pole.



STEP 12 - Loosen the guy rope as shown to wrap around a stake.



STEP 13 - Stake down the guy rope.



STEP 14 - Adjust the tension on the guy rope by sliding the clew up or down.



STEP 15 - Your shelter is now ready to use.

WARNING:

Texsport shelter fabrics are flame retardant treated per C.P.A.I.-84 specification. However, for your safety, we recommend that NO OPEN FLAME BE USED IN OR NEAR YOUR SHELTER.

SOME ADDITIONAL INFORMATION:

Always secure your shelter (with the shelter stakes included). Stake one corner, then stake each consecutive corner in a clockwise rotation. Make sure the shelter remains tight. Always place your shelter a safe distance from your campfire - unstaked shelter placed upwind of the fire can be blown into the fire. Shelter placed downwind of the fire are often showered with tiny sparks that can burn holes into the lightweight fabrics of your shelter.

WATERPROOFING YOUR SHELTER:

Texsport shelters are made from coated water-repellent fabrics. However, the sewing process, necessary in all shelter fabrication, can cause water leakage where the sewing needles have perforated the fabric in the seams. Without treatment the shelter will leak. Every new shelter needs to be seam sealed to make it water tight. We recommend using Texsport Spray Waterproofing/Seam Sealer which may be found at your local outdoor outfitter or camping store. DO NOT APPLY SEAM SEALER TO ZIPPERS.

STAKES:

All shelters should be staked down. The stakes supplied with your shelter are effective for most conditions; however, specialized stakes are recommended in certain cases:

- a. Sand Stakes:Long broad stakes designed to hold in loose sand.
- b. Steel Stakes:Most effective in hard, rocky or frozen soil. These can rust and their sharp edges could damage the shelter if stored with the shelter. Inextremely hard soil a steel rod can be used to make the starter hole.
- c. Skewer Stakes:Lightweight, but less holding power than the standard stakes.
- d. Snow Stakes:The most common method is to bury objects with a great deal of surface area in the snow i.e. branches, aluminum pie plates, stuff sacks orshelter bags filled with snow and buried: (this may be referred to as the dead man method). Shelters can also be secured to snow skis or poles which are stuck into the snow.

ZIPPERS:

If zippers stick, lubricate with silicone. Never force a zipper which has material caught in it as this will bend the slider and prevent the zipper from closing. Continual use in a sandy environment can cause the slider to erode and fail to close the zipper.

STORAGE:

Shelters should be stored dry and loosely folded away from heat and water. Keep out of reach of mice as they like to nest in shelters. Never store directly on concrete as moisture and chemicals in concrete may damage the nylon.

WASHING:

Hand wash with a sponge using a mild soap. Never use detergents or washing machines as they may damage the coating or seams. Remember to use seam sealer once shelter has been washed to insure waterproofing.

REPAIR:

For small tears use an adhesive backed rip-stop nylon patch. We recommend Texsport Nylon Shelter Repair Kit (#14113) which may be found at your local outdoor outfitter or camping store.

QUESTIONS:

If you should have any questions, problems or comments, please call our Customer Service Department at **1-800-231-1402** or e-mail **info@texsport.com**. This Department is open M-F from 8 a.m.-5 p.m. CST.