

## HOW TO USE

- **Open the valve and the pad unrolls while it self inflates.**
- **It only takes a couple minutes to fully inflate.**
- **Close the valve and the pad is ready to use.**
- **To deflate, open the valve the mattress can be tightly rolled up forcing air out. Close the valve and the pad will remain compact and ready for packing**

### REPAIR KIT INSTRUCTION:

**Repairing Small Punctures:** To locate small, pinhole-type punctures, inflate the item as firmly as possible by mouth. Immerse the item in water. Small escaping bubbles will indicate puncture location. Mark the puncture. Dry the item and deflate it. Work a drop of adhesive into the puncture. Let adhesive cure for 30 minutes before using the item.

**Repairing Larger Punctures:** Wipe dirt and moisture from the puncture. Sparingly apply the adhesive to the puncture. With circular motions, spread adhesive outward from the puncture. Trim a patch 1" beyond damaged area. Round the corners and remove paper backing. Lightly coat the patch with adhesive. Avoid touching the glue surface. After solvent has evaporated and patch/mat are dry to touch (approx. 3min), center the patch over damaged area and press gently to remove bubbles or wrinkles. Allow patch to cure for 10 minutes or longer before re-inflating the item for use.

**Damp Conditions:** Even if item is damp, a permanent repair can be made. However, allow at least 30 minutes for the patch to cure. During this curing period, handle the item with care.

### Freezing Temperatures

The adhesive becomes stiff with cold and difficult to squeeze from the tube. Warm the tube with body heat for 5-10 minutes. After applying patch at temperatures near or below freezing, allow 30 minutes or more curing time for the patch.

#### **Danger!! Extremely Flammable!!**

Do not use near heat, sparks and open flames. Contains petroleum distillate. Use only in well ventilated areas. Avoid prolonged breathing of vapor, Avoid eye contact, Avoid prolonged or repeated contact with skin. Suggested First Aid: for eye contact, immediately flush with plenty of water for at least 10 minutes and call a physician. If swallowed, do not induce vomiting, call a physician immediately. Keep container closed when not in use.

**WARNING!** Keep out of reach of children.

